

The **Cardinal** template for:
PowerUp 3.0; PowerUp Free Flight (2.0)
Paper type - 80 to 100 GSM
Paper size - A4
Printer setting - Scale 100% borderless


Copyright © 2015 TailorToys L.L.C. All rights reserved.
PowerUp® is a trademark of TailorToys L.L.C.

www.poweruptoys.com




Elevator


Elevator




1. Start with the printed template face up. Fold in half, the lower edge to the top edge. Unfold. Turn over.




2. Fold the right edge inward; follow the printed crease line (printed on the other side).




3. Fold the lower right corner along the marked crease line.




4. Fold the upper right corner along the marked crease line.




5. Bring the inner lower corner to the center of the front lower edge (the new crease line is parallel to this edge).




6. Repeat on the other flap.




7. Fold the new corner to the marked circle (printed on the other side).




8. Fold the Marked (*) corner to the printed circle.




9. Repeat on the other side.




10. Fold the lower wing backward along the center line.




11. Fold the wing down along the marked crease line - this line is not parallel to the center line! On the right, the crease starts where the bulk of layers end.



12. Fold the wing tip up, along the printed line.



13. Repeat steps 11-12 on the other wing.



14. Spread the wings. Cut the elevators. Note that this model has no rudder. Your Cardinal is ready!